

# miRNA and isomiR annotation

Lorena Pantano  
HSPH

Dec-15-2016

# Agenda

- miRNA and isomiR definition
- miRNA mapping comparison
- isomiR annotation strategy
- isomiR annotation from BAM files
- isomiR analysis in R

# miRNA

RNA molecules of 18-36 nts  
long with regulation  
function




# isomiR

<u>hsa-miR-24-1-5p</u>	<u>hsa-miR-24-3p</u>
..... <u>GGUGCCUACUGAGCUGAUAUC</u> .....	
..... <u>GUGCCUACUGAGCUGAUAUCAGU</u> .....	
..... <u>GUGCCUACUGAGCUGAUAUCAG</u> .....	
..... <u>GUGCCUACUGAGCUGAUA</u> .....	
..... <u>UGCCUACUGAGCUGAUAUCA</u> .....	
..... <u>UGCCUACUGAGCUGAUAUCAGU</u> .....	
..... <u>UGCCUACUGAGCUGAUAUC</u> .....	
..... <u>UGCCUACUGAGCUGAUA</u> .....	
..... <u>CCUACUGAGCUGAUAUCA</u> .....	
..... <u>CCUACUGAGCUGAUAUCAGU</u> .....	
..... <u>CUACUGAGCUGAUAUCA</u> .....	
..... <u>CUACUGAGCUGAUAUC</u> .....	

CUCCGGUGCCUACUGAGCUGAUAUCAGUUCUCAUUUUACACACUGGCUCAGUUCAGCAGGAACAGGAG  
(((((((((.....)))))))).))))))((-26.32)

precursor


# Types of isomiRs




# Protocols

## Critical differences in small RNA library preparation protocols

### Issue 1: Adapter ligation introduces bias




### Issue 2: Adapter dimers compete with small RNAs, reducing effective sequencing depth




# Protocol comparison

Paper figure




bcbio pipeline





# miRNA mapping






# Benchmark

- simulation of miRNAs/isomiRs (~ 16000)
- mapping with different tools
- compare miRNA detection and accuracy


# tools compared

bowtie, bowtie2, blast, GEM, microzer, miraligner, miraligner-python, novoaling, razer3, STAR, megablast


# miRNA detection



# Cause of missing



# miRNA accuracy



# isomiR annotation



UPPER CASE: addition  
lower cases: deletion

mismatch      addition  
trimming 5'    trimming 3'

miRNA\_name:mismatch:addition:t5:t3

hsa-let-7a-5p:0:0:GT:t

# tools compared

bowtie, bowtie2, GEM, miraligner, novoaling, razer3, STAR

```
mirtop annotate --sps hsa  
--hairpin ../hairpin.hsa.fa  
--mirna ../miRNA.str  
-o gem_out ../gem/sim.21.hsa.sam
```

You can input multi-bam files at the same time



# open project for small RNA annotation and analysis

The screenshot shows the GitHub repository page for mirTOP. The repository name is "mirTOP" with the description "miRNA transcriptome open project" and the URL "http://mirtop.github.io". The page includes a navigation bar with "Repositories", "People 3", "Teams 1", and "Settings". Below the navigation bar is a search bar with the text "Find a repository..." and a "New repository" button. The repository list shows three items: "incubator" (1 star, 1 fork), "mirtop" (Python, 0 stars, 0 forks), and "miRTOP.github.io" (CSS, 0 stars, 0 forks). Annotations are overlaid on the image: "standard formats naming rules" in blue text over the "incubator" repository, "best-practices" in green text over the "mirtop" repository, and "miRNAs, tRNAs ..." in orange text over the "miRTOP.github.io" repository.

**mirTOP**  
miRNA transcriptome open project  
<http://mirtop.github.io>

**Repositories** People 3 Teams 1 Settings

Filters Find a repository... New repository

**incubator** ★ 1 🍴 1  
Where all ideas and discussions happen to lead to new repositories  
Updated 3 days ago

**mirtop** Python ★ 0 🍴 0  
command lines tool to annotate miRNAs with a standard mirna/isomir naming  
Updated 3 days ago


**miRTOP.github.io** CSS ★ 0 🍴 0  
project for small RNA standard annotations  
Updated on Mar 29

**standard formats naming rules**

**best-practices**


**miRNAs, tRNAs ...**

# isomiR from BAM file



# isomiR comparison

Specificity at miRNA level



# miRNA with R

- what to consider as input for the DE tools
- isomiR characterization
- query the data
- Supervised clustering with feature selection

# Input

seq	name	freq	mir	start	end	mism	add	t5	t3	s5	s3	DB	precu
AGGTCGACCGTGTTATATTCG	seq_100056_x3	3				rno-miR-369-5p		14	34	3GA	0	0	c
TTGAAAGGCTGTTTCTTGTT	seq_100058_x15	15				rno-miR-488-3p		49	68	0	T	0	c
TACTGCACTCGTCCCGGCCT	seq_100063_x3	3				rno-miR-92b-3p		52	71	3CT	0	0	cc
TTGAAAGGCTGTTTCTTGTTG	seq_100069_x33	33				rno-miR-488-3p		49	68	0	G	0	c
CTACTTCACAACACCAGGGTTA	seq_10011_x13	13				rno-miR-138-1-3p			64	83	0	TA	cgg
TGAGGTAGTAGTTTGTGCTGAT	seq_100122_x3	3				rno-let-7i-5p		6	25	0	AT	0	tt
TCTACAGTGCACGTGCCTCCA	seq_100131_x5	5				rno-miR-139-5p		7	27	16CT	0	0	g
ACGTCATCGTCGTCATCGTTA	seq_100132_x5	5				rno-miR-598-3p		49	69	0	0	t	0
TGTGACAGATTGATAACTGAAAG	seq_100147_x11	11				rno-miR-542-3p		49	71	0	0	0	G
CTGGCCCTCTCTGCCCTTCCGCAT	seq_100148_x9					rno-miR-328a-3p		9	48	68	0	CAT	0
NGAATTGTGGCTGGACATCTGT	seq_100185_x4	4				rno-miR-219a-2-3p			62	83	1NA	0	0
GGAAGACTAGTGATTTTATTGT	seq_100227_x5	5				rno-miR-7a-5p		20	41	18AG	0	t	0
AACATTTATTGCTGTCGGTGGGT	seq_100277_x8	8				rno-miR-181b-5p		15	37	7TC	0	0	0

# Processing annotation

```
<<package-plot-iso,message=FALSE,eval=FALSE>>=
ids <- IsomirDataSeqFromFiles(fn_list, design=de)|
@
```

Order in fn\_list should be the same than in the design data.frame


```
> fn_list
[1] "/Library/Frameworks/R.framework/Versions/3.3/Resources/library/isomiRs/extra/sample1.mirna"
[2] "/Library/Frameworks/R.framework/Versions/3.3/Resources/library/isomiRs/extra/sample2.mirna"
```

```
> de
  condition
f1  newborn
f2  newborn
```

# isomeR figures

Higher in figure means different sequences with that isomiR type

Bigger the size of the dot means expression of that isomiR type is higher






# DE analysis

- DESeq2 as in RNAseq
- Sometimes filtering miRNA by group can help to increase power.
- limma-voom strategy should work equally

# Correcting quantification

PCR amplification and ligase bias correction factors

D




# Clustering



```
ids = isoCounts(ids, iso5=TRUE, minc=10, mins=6)
ids = isoNorm(ids)
pls.ids = isoPLSDA(ids, "condition", nperm = 2)
df = isoPLSDAplot(pls.ids)
```

```
> head(pls.ids$vip)
```

	variable	VIP
hsa-let-7c-5p.t5:GT	hsa-let-7c-5p.t5:GT	1.518223
hsa-let-7d-5p.t5:0	hsa-let-7d-5p.t5:0	1.533554
hsa-let-7f-5p.t5:tg	hsa-let-7f-5p.t5:tg	1.421619
hsa-let-7i-5p.t5:0	hsa-let-7i-5p.t5:0	1.356090
hsa-let-7i-5p.t5:t	hsa-let-7i-5p.t5:t	1.525162
hsa-miR-1.t5:0	hsa-miR-1.t5:0	1.383350



# mRNA-miRNA interaction




+

GO  
enrichment

targetscan  
targets

negative  
regulation

# Output of target analysis



# Conclusion

- mapping to precursor and parsing with mirtop
- participate in the open project for miRNA annotation
- analyze isomiRs as well (isomiRs)
- DESeq2 for differential expression (my experience)
- mRNA-miRNA paired data helps incredible for downstream analysis